

TC350P

Instructions
for converting non sensor
to sensor type

ENGINEQUEST

(800) 426-8771 toll free
(702) 649-7776 local
(702) 649-6777 fax
www.enginequest.com

This cover is designed to be universal. If you require the sensor hole to be open Follow these steps...

1. Drill or punch out the 3/4" sensor hole.
2. Drill a 23/64" hole for the insert.
3. Use a rubber mallet to pound in the insert.



TC350P

Instructions
for converting non sensor
to sensor type

ENGINEQUEST

(800) 426-8771 toll free
(702) 649-7776 local
(702) 649-6777 fax
www.enginequest.com

This cover is designed to be universal. If you require the sensor hole to be open Follow these steps...

1. Drill or punch out the 3/4" sensor hole.
2. Drill a 23/64" hole for the insert.
3. Use a rubber mallet to pound in the insert.

